

Blue Bliss Radiance Boosting Mask

Sr No.	INCI Name, Trade Name	Weight %	Function
Phase A			
1.	Water	QS upto 100	Solvent
2.	BTMS 50*	1.45	Conditioning active
Phase B			
3.	Glycerin*	12.00	Humectant
4.	Xanthan Gum*	0.40	Thickener
5.	Magnesium Aluminum Silicate	3.20	Suspending agent
Phase C			
6.	Serebian Blue Clay*	15.00	Detoxifying Clay
7.	Kaolin*	15.00	Purifying Clay
8.	Decyl Glucoside*	2.00	Surfactant
Phase D			
9.	Novaguard 700*	0.80	Preservative
10.	Parfum	0.20	Perfume
Phase E			
11.	Lactic Acid (90%)	QS to adjust pH	pH adjuster

***These materials are supplied by Cedar Trends & Innovation**

Procedure:

- Pre-mix the ingredients of phase A and heat at 75-80°C.
- Pre-mix phase B.
- Add phase B into phase A under agitation. Heat at 75-80°C under moderate agitation in order to create a homogeneous paste.
- Add the ingredients of phase C one by one to the paste under heat (75-80°C) and agitation until a homogeneous paste is formed.
- Allow to cool under agitation until the paste reaches 40°C then add phase D.
- Check that the pH is between 4.0 – 4.5 with phase E.